



Corrosion Chambers with Recirculating Air and Alternating Climate Control SaltEvent SC/UKWT



Test whatever you like.

From boot to bonnet - in research, development and quality control, you won't want to take any chances. We'll support you.



Corrosion firmly under control.

High humidity, salty air, seawater, and gritting salt - many small and large things in daily life are exposed to corrosive atmospheres. Corrosion does not just affect base metals, but also high-alloyed, tempered materials, plastics, and painted surfaces. That's why corrosion resistance is an important quality indicator and safety feature for many products. With the **weisstechnik** Corrosion Chambers with Recirculating Air and Alternating Climate Control SaltEvent SC/UKWT, you can simulate the effect of salt spray, condensation, and standard climates - individually, combined, and automatically. Reproducible, certified, and under accelerated conditions.

Lots to test? No problem!

When testing your products, you must adhere to numerous test standards and carry out long-term tests. Our test chambers are designed for these situations. Our models cover a wide range of applications and satisfy every need. For specific requirements, you can upgrade every system with many options based on your individual needs.

Perfection in performance, equipment and design.

Corrosion Chambers with Recirculating Air and Alternating Climate Control SaltEvent SC/UKWT.

Completely thought through.

We know what matters for your tests: reliable, precise and reproducible results. That's why we design our test chambers to meet exactly these demands. Because incorrect results lead to incorrect conclusions. With this in mind, we already eliminate any interference factors during the design phase, relying on our comprehensive expertise and years of experience.

Perfectly manufactured.

For us, quality is our daily business. We use only high quality materials and manufacture many of the components for our test chambers in-house. In addition, we also have regular quality checks in place throughout the entire production process.

Absolutely low maintenance.

Set up, plug in, start the test. No installation necessary. The intelligent, compatible control elements and intuitive user interface guarantee easy operation. Easily accessible maintenance elements ensure minimal service times. Diagnostics and inspection systems in every machine additionally shorten downtimes and optimise maintenance periods.



Reliable measurement results are possible thanks to:

- Optimal spray mist distribution due to a precision two-component nozzle
- Extremely stable temperatures due to a double-shell construction with internal insulation and heated compressed air humidifier with water level control
- Adjustable flow meter and doser for solution
- Test space and hood construction in accordance with all standards: any droplets created by the spray cannot drip on the samples tested.

More equipment, right from the start.

Basic equipment setting standards.

Exterior



- **Everything is sealed**

The hood and test chamber are hydrostatically sealed using a U-shaped profile. The resulting groove is automatically filled with demineralised water and prevents salt spray from getting into the laboratory - safely and permanently.

Interior



- **Stay flexible**

The brine solution required for the tests is stored in a removable, portable brine tank. This tank is easy to clean and can be fully disconnected without using any tools if required.

- **Great climate**

In the controlled climate operation, the air in the test space is conditioned by an air-conditioning unit in recirculation mode. This ensures very stable environmental conditions and, as a result, a high degree of precision in the testing.

- **Fully automatic**

A solenoid valve feeds demineralised water into the compressed air humidifier and fills the test space for the humidity test matching the requirements given in DIN EN ISO 6270-2. Draining water from the test space is also done automatically.

Regulation & Control



- **Into the age of connectivity - with WEBSeason®**

You can use the innovative user interface **WEBSeason** to program, control and monitor your tests at any time and anywhere, even from your tablet or smartphone. Language and units can be set to suit the user and the settings can be saved. In this way, **WEBSeason** provides a new dimension of flexibility and efficiency.



You can find further details on equipment in our technical descriptions. **Contact us.**



Illustration is similar, contains options

Reliable control as a standard:
Digital measurement and control system for
operating and monitoring the test chamber.



Tailor-made testing.

Optional equipment for individual solutions.



Illustration is similar, contains options

Exterior



- **Everything in view**

Thanks to a camera, you always know the state of your test pieces - without having to interrupt the test by opening the hood. This reduces the testing time and your testing will produce more precise results.

Interior



- **Precise measurements**

You can measure the corrosive precipitation rate automatically at up to 8 points in the test space. The mean value of the precipitation rate is displayed and updated throughout the test.

- **Accelerated testing**

You can subject your test pieces to an additional hardness test with direct spraying. Here the spray solution is sprayed directly above the test specimen by means of an automatic spray duct in the test space hood.

- **More mist**

For special test requirements, the precipitation quantity can be increased from standard 1.5 ml/80 cm²/h to 5.0 ml/80 cm²/h.

Regulation & Control



- **Set standards in communication**

With software **SIMPATI**[®], operating, documenting and archiving your test sequences is as easy as child's play.

You can find further details on equipment in our technical descriptions. **Contact us.**

Developed exclusively for you:
The unique software package
for the perfect test process.



Convincing technology. Reliable results.

The performance data at a glance:

Type		SaltEvent SC/UKWT 1000	
Test space volume		l	1028
Test space dimensions¹	Height with hood	mm	1140
	Height without hood	mm	720
	Width	mm	1670
	Width with spray duct	mm	1560
	Depth	mm	645
Exterior housing dimensions incl. air conditioning unit^{1,2}	Height	mm	1370
	Width	mm	2925
	Depth	mm	1880
Temperature range	Salt spray test Condensed water test Climate operation Drying/ventilation		5 K above ambient temperature up to +50 °C 5 K above ambient temperature up to +42 °C +23 up to +70 °C 5 K above ambient temperature up to +70 °C
Dewpoint range	Climate operation	°C	+12 bis +69
Temperature stability³ in time	Salt spray test	K	±1.0
	Condensed water test	K	≤ ±2.0
Humidity range	Climate operation	% r.F.	20.0–98.0
	Drying/ventilation	% r.F.	≤ 30.0
Humidity deviation in time	Climate operation	% r.F.	≤ ±5.0
Water consumption	Salt spray test ³	l/h	0.4
	Condensed water test	l	34.0
Consumption of brine	Salt spray test	l/h	0.9
Air throughput⁴	Salt spray test	m ³ /h	2.0
	Ventilation	m ³ /h	15.0
Calibration values⁵ for test space temperature	Salt spray test	°C	+35
	Condensed water test	°C	+40
Calibration values⁵	Climate operation	°C/% r.F.	23/50 and 50/95
Calibration value⁵ for pressure humidifier temperature	Salt spray test	°C	+49

¹Production-related tolerances of up to ±10 mm are possible.

²Exterior housing dimensions when divided: System (H x W x D/mm) 1370 x 2925 x 980, air conditioning unit (H x W x D/mm) 910 x 2120 x 900.

³The evidence of temperature stability takes place at ambient temperature of +23 °C ±2 K in the middle of the test space when this is empty and in a steady state, without specimen, heat radiation and optional equipment.

⁴At 0 °C and 1 bar.

⁵Factory calibration.

The performance data refer to +23 °C ±2 K ambient temperature, 230 V/50 Hz nominal voltage, without specimen and without optional equipment. The permitted ambient temperature is between +18 and +30 °C. The max. permitted humidity must not exceed 75% RH.

We reserve the right to make any technical changes without prior notice.

Become more efficient.

Our solutions will save you time and money.

Get the most out of your test facility.

Create your own perfect testing process with the software package SIMPATI®.



Process management/Documentation/Networking

- Up to 99 systems can be connected
- Programs for automated processes
- Documentation, visualisation and management of process data
- Traceability of process data for seamless quality control



We measure ourselves by our service!

Our services - lots of good arguments:

- Global service network
- Wide selection of preventive maintenance
- Reliable spare part supply
- Special deployments available any time
- Certified proper disposal of outdated devices

You can always find a **weisstechnik** expert near you.

24/7 Service Helpline:
+49 1805 666 556

Passionately innovative.

We work in partnership to support companies in research, development, production and quality assurance. With 22 companies in 15 countries at 40 locations.

weisstechnik

Test it. Heat it. Cool it.



Environmental Simulation

The first choice for engineers and researchers for innovative, safe environmental simulation facilities. In fast motion, our test systems can simulate all the influences in the world as well as for instance in space. In temperature, climate, corrosion, dust or combined stress tests. With a very high degree of reproducibility and precision.



Climate Technology, Air Dehumidification, Clean Rooms

As the leading provider of clean rooms, climate technology and air dehumidification, we consistently ensure optimal climatic conditions for people and machines. For industrial production processes, in hospitals, mobile operation tents or in the field of information and telecommunications technology. From project planning to implementation.



Heat Technology

Experienced engineers and designers develop, plan and produce high-quality, reliable heat technology systems for a broad range of applications from heating and drying cabinets to microwave systems and industrial furnaces.



Clean Air and Containment Systems

With decades of experience and know-how, we guarantee the most sophisticated clean air and containment solutions. Our comprehensive and innovative range of products includes barrier systems, laminar flow systems, safety workbenches, isolators and airlocks.

Weiss Umwelttechnik GmbH

Greizer Straße 41-49
35447 Reiskirchen/Germany
T +49 6408 84-0
info@weiss-technik.com
www.weiss-technik.com



UT-SaltEvent-SC/UKWT-01.2E/PP 1.0/07 2018